

## Wall 2300 with no door

This module will enable you to construct a 2300mm x 1900mm wall with no door that will be used in your new garden shed.


### Before you begin the build

Just like our sheds, our manuals are designed in modules to make assembly easier and simpler. Your shed will have come in 5 or 6 boxes that are easy to handle. Each carton contains one shed module together with instructions on how to assemble that module. You begin by assembling your wall modules, then your roof modules and finally you put those modules together to erect your shed.

The key to a hassle free shed assembly is to take your time and have your work area and shed base well prepared prior to starting the build. We suggest that before you go any further, if you haven't already, locate your roof module carton and find the instructions. The roof module instructions contain details on site preparation, your first job, and module assembly and anchoring your shed to the base. **So before you go any further, read the roof module instructions, it will save you time and frustration.**

If you have already read about site preparation – onward.


### *Tools you will need.*




## Check the contents

Before you start to construct this wall you will need to check off all of the contents.

### Parts checklist for a 2300 wall with no door

Picture	Description	Component	Location	Part No.	QTY	Check
	Sheet	Sheet 1900x770	Wall	9M	3	
	Channel	Channel 1124	Wall	26C	1	
	Channel	Channel 1124	Wall	26D	1	
	Channel	Channel 1124	Wall	SC06	1	
	Channel	Channel 1124	Wall	SC07	1	
	Channel	Channel 1070	Wall	SC08	1	
	Channel	Channel 1070	Wall	SC09	1	
	Jamb	Jamb 1898	Wall	SZ01	1	
	Channel connector	Channel connector 188mm	Wall	66	2	

**Fittings Pack**

Picture	Component	QTY	Picture	Component	QTY
	Self tapping screws(10mm)	48		Mid wall channel connector	1

**If you are missing anything call The Garden Shed Hotline 1300 781 230**

## Start the Build

Here is what you are building. It is a 2300mm wide x 1900mm high wall without any door. This type of wall is typically a side or back wall for your shed.




Diagram 1 – View from the inside

### Assembly Instructions

- 1 Place 3 x 9M sheets on your work table. Fix each sheet together with 3x10mm self-tapping screws as per diagram 2.





Diagram 2


**Handy Hint** – Never attempt to assemble a garden shed on a windy day. You will need to store your assembled walls in a safe place before the final assembly stage.

- 2 Now fit 26D and 26C bottom channels as per diagrams 3 & 4 below using 10mm self-tapping screws. The narrow lip of the channel is always facing the outside of your shed. Now fit SC07 and SC06 top channels. You can either tap or slide the channels into position.



**A**

*Diagram 3 – Tap on channels*



**B**

*Diagram 4 – Slide on channels*

- 3 Fix the 66 connectors top and bottom as per diagram 5. Then fit SC09 and SC08 mid wall channels and join in the middle with mid wall channel connector as per the diagram. Do not insert the screws marked with the cross now, you will insert these at a later stage.





Diagram 5

- 4 Take the corner angle SZ01 and attach it to the left hand edge of your wall. This will be used to join other walls later.



**You have now completed the assembly of this module**

### **What's next?**

You will have some screws left over. Don't worry you haven't forgotten anything; we give you more than you need.

Put your 2300mm x 1900mm wall to one side in a safe place where it won't get stepped on, blown over or otherwise damaged and move onto the next wall. If this was the fourth wall you have constructed the next job is the roof.