

Wall 3000 with double sliding doors

This module will enable you to construct a 3000mm x 1900mm wall with a double sliding door that will be used in your new garden shed.


Before you begin the build

Just like our sheds, our manuals are designed in modules to make assembly easier and simpler. Your shed will have come in multiple boxes that are easy to handle. Each carton contains one shed module together with instructions on how to assemble that module. You begin by assembling your wall modules, then your roof modules and finally you put those modules together to erect your shed.

The key to a hassle free shed assembly is to take your time and have your work area and shed base well prepared prior to starting the build. We suggest that before you go any further, if you haven't already, locate your roof module carton and read these instructions. The roof module instructions contain details on site preparation, your first job, and module assembly and anchoring your shed to the base. **So before you go any further, read the roof module instructions, it will save you time and frustration.**

If you have already read about site preparation – onward.











Tools you will need.












Check the contents








Before you start to construct this wall you will need to check off all of the contents.

Parts checklist for a 3000 wall with a double sliding door

Picture	Description	Component	Location	Part No.	QTY	Check
	Door	Sheet 1868x770	Door	5A	1	
	Door	Sheet 1868x770	Door	5F	1	
	Sheet	Sheet 1900x735	Wall	SS06	2	
	Channel	Channel 1868	Door	SC29	1	
	Channel	Channel 1868	Door	SC30	2	
	Channel	Channel 768	Door	21P	4	
	Jamb	Jamb 1853	Door	J6	1	
	Brace	Brace 1075	Door	U4	4	
	Channel	Channel 1514	Wall	C26	2	
	Channel	Channel 1494	Wall	27S	1	

Picture	Description	Component	Location	Part No.	QTY	Check
	Channel	Channel 1494	Wall	27T	1	
	Channel	Channel 1494	Wall	SC36	1	
	Channel	Channel 1494	Wall	SC37	1	
	Channel	Channel 1898	Wall	22E	2	
	Bottom Track	Bottom Track 1445	Wall	SO11	1	
	Bottom Track	Bottom Track 1445	Wall	SO12	1	
	Top Track	Top Track 1445	Wall	SO07	1	
	Top Track	Top Track 1445	Wall	SO08	1	
	Jamb	Jamb 1898	Wall	SZ01	1	
	Track connector	Track connector 178mm	Wall	66A	2	
	Brace	Brace	Door	w	2	

Fittings Pack

Picture	Component	QTY	Picture	Component	QTY
	Self tapping screws(10mm)	15		Self tapping screws(16mm)	40
	Hasp (C4)	1		Staple	1
	White plastic stopple	8		3*10mm Rivet	68
	4*10mm Rivet	24			

If you are missing anything call The Garden Shed Hotline 1300 781 230

Start the Build

Here is what you are building. It is a 3000mm wide x 1900mm high wall with a double sliding door. This type of wall is typically a side or front wall for your shed.




Diagram 1

Assembly Instructions

- 1 Place the 5A sheet on your workbench. Attach 2 x 21P, SC30 and SC29 channels using 3.0*10mm rivets as per diagram 2.




Diagram 2

- 2 Place the 5F sheet on your workbench. Attach 2 x 21P, SC30 channel and J6 jamb using 3.0*10mm rivets as per the diagram below.




Diagram 3

- 3 Now attach W and U4 door bracing using 3.0*10mm rivets as per diagrams 4 & 5 below. Fit the white plastic stopple as per diagram 5 to ensure no sharp edges. Repeat this process for your second door.




Diagram 4




Diagram 5

- 4 Place 2 x SS06 sheets on your work table. Now fit 2 x 22E channels. Do not insert the screws marked with the cross now, you will insert these at a later stage.





Diagram 6

5 Now fit 27T and 27S bottom channels as per diagram 7. The narrow lip of the channels always facing the outside of your shed. Now fit C26 bottom channel, SO11 and SO12 bottom track and 66A track connector. Use the 16mm self tapping screws. Repeat this process for the top as per the diagram.



Fix all by 16mm self tapping screws in this stage

Diagram 7

- 6 Slide the doors into position as per diagram 8 below. Fix hasp and staple using 4.0*10mm rivets.




Diagram 8

- 7 Take the corner angle SZ01 and attach it to the left hand edge of your wall. This will be used to join other walls later.




Diagram 9

You have now completed the assembly of this module

What's next?

You will have some screws left over. Don't worry you haven't forgotten anything; we give you more than you need.

Put your 3000mm x 1900mm wall with double sliding doors to one side in a safe place where it won't get stepped on, blown over or otherwise damaged and move onto the next wall. If this was the fourth wall you have constructed the next job is the roof.