

## Wall 1500 with a single sliding door

This module will enable you to construct a 1500mm x 1900mm wall with a single sliding door that will be used in your new garden shed.


### Before you begin the build

Just like our sheds, our manuals are designed in modules to make assembly easier and simpler. Your shed will have come in 5 or 6 boxes that are easy to handle. Each carton contains one shed module together with instructions on how to assemble that module. You begin by assembling your wall modules, then your roof modules and finally you put those modules together to erect your shed.

The key to a hassle free shed assembly is to take your time and have your work area and shed base well prepared prior to starting the build. We suggest that before you go any further, if you haven't already, locate your roof module carton and find the instructions. The roof module instructions contain details on site preparation, your first job, and module assembly and anchoring your shed to the base. **So before you go any further, read the roof module instructions, it will save you time and frustration.**

If you have already read about site preparation – onward.



### *Tools you will need.*





## Check the contents




Before you start to construct this wall you will need to check off all of the contents.

### Parts checklist for a 1500 wall with a single sliding door

Picture	Description	Component	Location	Part No.	QTY	Check
	Door	Sheet 1868x770	Door	5A	1	
	Sheet	Sheet 1900x735	Wall	SS06	1	
	Channel	Channel 1868	Door	SC29	1	
	Channel	Channel 1868	Door	SC30	1	
	Channel	Channel 768	Door	21P	2	
	Brace	Brace 1075	Door	U4	2	
	Channel	Channel 1508	Wall	20K	1	
	Channel	Channel 1508	Wall	SC28	1	
	Channel	Channel 723	Wall	23H	2	
	Channel	Channel 1898	Wall	22D	1	
	Channel	Channel 1898	Wall	22E	1	

Picture	Description	Component	Location	Part No.	QTY	Check
	Jamb	Jamb 1898	Wall	C1	1	
	Jamb	Jamb 1898	Door	SZ03	1	
	Bottom Track	Bottom Track 1434	Wall	SO09	1	
	Top Track	Top Track 1434	Wall	SO01	1	
	Brace	Brace	Door	W	1	

**Fittings Pack**

Picture	Component	QTY	Picture	Component	QTY
	Self tapping screws(10mm)	15		Self tapping screws(16mm)	35
	Hasp (C4)	1		Staple	1
	White plastic stopple	4		3*10mm Rivet	35
	4*10mm Rivet	16			

**If you are missing anything call The Garden Shed Hotline 1300 781 230**

## Start the Build

Here is what you are building. It is a 1500mm wide x 1900mm high wall with a single sliding door. This type of wall is typically a side or front wall for your shed.




Diagram 1

**Assembly Instructions**

- 1 Place the 5A sheet on your workbench. Attach 2 x 21P, SC30 and SC29 channels using 3.0\*10mm rivets as per diagram 2.




Diagram 2

- 2 Now attach W and U4 door bracing using 3.0\*10mm rivets as per diagram 3. Fit the white plastic stopple as per diagram 4 to ensure no sharp edges.




Diagram 3




Diagram 4

- 3 Place the SS06 sheet on your work table. Fit 20K bottom channel as per diagram 5 using 10mm self-tapping screws. The narrow lip of the channel is always facing the outside of the shed. Fit SC28 top channel, then fit 22E jamb. Do not insert the screws marked with the cross now, you will insert these at a later stage.




Diagram 5

- 4 Now fit SO01 top track and 23H and SO09 bottom track and 23H using 16mm self-tapping screws. Join 22D channel to C1 jamb using 16mm self-tapping screws. Attach C1 jamb to frame using 16mm self-tapping screws as per diagram 6. Do not insert the screws marked with the cross now, you will insert these at a later stage.




Diagram 6

- 5 Slide the door into position and fix the hasp with 4\*10mm rivets as per diagram 7.




Diagram 7

6 Fix the staple using 4.0\*10mm rivets as per diagram 8.





Diagram 8

- 7 You will have the SZ03 jamb left over as per diagram 9. Put this into a safe place as you will use this in a later stage of the build.



*Diagram 9*

**You have now completed the assembly of this module**

## **What's next?**

You will have some screws left over. Don't worry you haven't forgotten anything; we give you more than you need.

Put your 1500mm x 1900mm wall with one sliding door to one side in a safe place where it won't get stepped on, blown over or otherwise damaged and move onto the next wall. If this was the fourth wall you have constructed the next job is the roof.